

## Calibration Table

### Ironflexx

	Disc/Vane type	Spreader height/tilt	Disc Speed	Spread width	Spread Setting	Application rate
<b>Bullock Tillage DeLimbe T28.3</b>	275mm 4 Vane	110cm	No.10	12m	Centre	4
		110cm	No.10	12m	Centre	7
		110cm	No.30	24m	Centre	4
		110cm	No.30	24m	Centre	7

	Disc/Vane type	Spreader height/tilt	Disc Speed	Spread width	Spread Setting	Application rate
<b>Logic TFS80P</b>	3 Vane	110cm	2700	12m	7	4
		110cm	2700	12m	7	7
		110cm	2700	15m	7	4
		110cm	2700	15m	7	7

	Disc/Vane type	Spreader height/tilt	Disc Speed	Spread width	Spread Setting	Application rate kg/ha
<b>Spaldings Lehner Super Vario</b>	2 Vane	100cm	3000	12m	1&5	4
		100cm	3000	12m	2&5	7
		100cm	3000	15m	1&5	4
		100cm	3000	15m	2&5	7

	Disc/Vane type	Spreader height/tilt	Disc Speed	Spread width	Spread Setting	Application rate
<b>Stocks Ag Fan Jet Pro 65</b>	2 Vane	120cm + 1degree	No.7	12m	Bias 90	4
		120cm + 1degree	No.7	12m	Bias 85	7
		120cm + 1degree	No.12	20m	Bias 90	4
		120cm + 1degree	No.12	20m	Bias 85	7

	Disc/Vane type	Spreader height/tilt	Disc Speed	Spread width	Spread Setting	Application rate
<b>Stocks Ag Fan Jet Duo</b>	4 Long Vane	150cm	No.10	24m	Bias 90	4
		150cm	No.10	24m	Bias 90	7
		150cm	No.12	32m	Bias 75	4
		150cm	No.12	32m	Bias 75	7

**NB. Information in these tables is only for guidance, settings may vary between machines. Make sure to calibrate individual machines before use.**