

## Application Settings Guide

This guide advises on applicator settings to give an even spread of pellets across the working width. For specific information on settings to achieve a given dose rate, please refer to the applicator handbook.

	Disc/Vane Type	Spreader Height/ Tilt	Rate Kg/Ha	Disc Speed	Spread Width	Spread Setting
<b>Bullock Tillage DeLimbe T28.3</b>	275mm 4 vane	110cm	4	No.10	12m	Centre
		110cm	7	No.10	12m	Centre
		110cm	4	No.30	24m	Centre
		110cm	7	No.30	24m	Centre

<b>Logic TSF80P</b>	3 vane	110cm	4	2700	12m	9
		110cm	7	2700	12m	10
		110cm	4	2700	15m	9
		110cm	7	2700	15m	10

<b>Spalding Lehner Super Vario</b>	2 vane	100cm	4	3000 rpm	12m	1 & 5
		100cm	7	3000 rpm	12m	2 & 5
		100cm	4	3000 rpm	15m	1 & 5
		100cm	7	3000 rpm	15m	2 & 5

<b>Stocks Ag Fan Jet Pro 65</b>	2 vane	120cm + 1°	4	No.7	12m	Bias 90
		120cm + 1°	7	No.7	12m	Bias 90
		120cm + 1°	4	No.12	20m	Bias 90
		120cm + 1°	7	No.12	20m	Bias 90

<b>Stocks Ag Fan Jet Duo</b>	4 long vane	150cm	4	No.10	24m	Bias 90
		150cm	7	No.10	24m	Bias 90
		150cm	4	No.12	32m	Bias 75
		150cm	7	No.12	32m	Bias 75

All settings at 12 Kph.

Settings provided in the spreading tables above are derived from practical tests in the field carried out by SCS Spreader & Sprayer Testing Ltd. Contact [info@spreadcheck.com](mailto:info@spreadcheck.com)